
BELLAGIO



Overall	Overall	Overall	Arm	Back Height	Seat	Arm	Inside Width	Seat Depth	Seat Depth
Height	Width	Depth	Height	of Frame	Height	Width	Arm to Arm	to Cushions	no Cushions
94cm / 37"	158cm / 62"	112cm / 44"	69cm / 27"	92cm / 36"	53cm / 21"	18cm / 7"	122cm / 48"	56cm / 22"	

Seating sizes vary to a great extent and particularly wherever there are soft cushions involved, this is magnified with front of seat to back cushion depths, whilst formal back cushions will vary with age and plumping. It is essential to note that scatter back cushion depths will adjust from which point you measure, overtime and with plumping, the accurate measurement does not exist as it will resize each and every time you enjoy its comfort.